

Combining key lessons learned from H2020 and FP7 projects to underpin the next generation of nanosafety research

Vicki Stone
Heriot-Watt University
v.stone@hw.ac.uk



A few things from past projects...

- Generated a wealth of data, especially on the hazards of engineered nanomaterials (NMs)
- We improved our understanding of the need for physicochemical characterisation, and how to do it
- We improved understanding of which physicochemical characteristics influence hazard
- We advanced methodologies for assessment of exposure
- We initiated templates for collection of data in a common format
- We initiated templates for method sharing





- We need to deliver 'tools' for stakeholders that are useful.
 - Useful for regulators and industry
 - Useful for regulatory purposes
 - Useful for innovation and safe(r) by design
- We need to make sure that the 'tools' generated by individual projects are sustainable and are utilised after each project is complete.



The evolution of nanosafety







- We have tools
- But they were not well organised or linked
- The quality is variable

- Our data is now well organised
- Our tool quality is being improved
- We have a great toolbox

- The toolbox needs to be accessible
- The tools need to be fit for different users and purposes
- Guidance needed
- Streamlined processes needed



• An accessible data repository.....





- The European NanoSafety database
- A computational infrastructure for toxicological data management of NMs
- Improved the utilisation of data through the implementation of data storage, searching and sharing
- Accelerating knowledge exchange and reuse
- Enabling the meta analysis of nano-bio interactions
- Instances generated for individual projects such as caLIBRAte, PATROLS and GRACIOUS – allow project partners to more readily access the most relevant data

http://www.enanomapper.net/enm




• Exploitation of data repositories to develop models of NM behaviour.....






Fate and Exposure models and tools for you – www.NanoFASE.EU







Fate and Exposure models and tools for you – <u>www.NanoFASE.EU</u> Delivered in a transparent online "Clickable Framework"



"Clickable" links for all elements:

- Product lifecycle release processes
- Environmental compartments
- Models for all Different complexity levels
- Protocols and Data

These links allow progressive access to deeper levels of details and protocols





Fate and Exposure models and tools for you – <u>www.NanoFASE.EU</u>

Delivered in a transparent online "Clickable Framework"




LEVEL 1 - CONCEPTS






Fate and Exposure models and tools for you - www.NanoFASE.EU



LEVEL 2 – DETAILED PARAMETERS & ALGORITHMS

NanoFASE

Nanomaterial Fate and Speciation in the Environment (2015-2019)





LEVEL 4 –
EXPERIMENTAL &
ALGORITHM OPTIONS
for
PARAMETERS
DETERMINATION

NanoFASE

HOME

Wastewater

Environmental Fat

Soils are exposed to ENMs mostly

contaminated soils, as nanofert

including food crops, also giving ar

Delivered in a transi

ENM Enab

Product Va

Chains and

Pathways

ENM

ENM Prod. Ma

Distribu

Synthe

Nanomaterial Fate and Speciation





in the Environme Soil batch tests

Attachment efficiency Fate and Exposure models an

Heteroaggrega

Heteroaggregation is an ag

heteroaggregation between


systems or in soils. Hetero

expressed by an attachn

than homoaggregation and

Fate descripto

Attachment efficiency (α) expresses the probability that upon co stick to each other. In the case of favorable attachment, lpha equa oppositely charged or when the ionic strength is relatively high. leading to steric hindrance or charges on the particle surfa hydrodynamics, determines the attachment rates in porous heteroaggregation rates in rivers and wastewater treatment plan



Algorithms

 $v = \alpha \beta n^2$


Read more

NanoFASE Report D7.2 Soil property - NM fate relationships

NanoFASE Report D8.1 Alignment between model requiremen xperimental procedures

Batch testing can be used in the laboratory to measure the attachment efficiency (a) of nanoparticles to soil.

Batch testing provides an alternative to column tests, and while the same parameters can be employed, batch testing provides a somewhat simplified approach, allowing larger datasets to be readily obtained.



- 1. A matrix (artificial rainwater) of known volume is mixed with a known mass of soil (sieved to 2mm).
- 2. Nanoparticles of known size and concentration are added, providing a known solid:liquid ratio.
- 3. The solution is constantly stirred and aliquots collected by syringe along a front-loaded time series gradient.
- 4. The batch test is then repeated using the same liquid:solid ratio and soil sample, with the addition of a known quantity of salt, increasing the ionic strength of the sample such that the attachment efficiency (α) equals


Mechanisms & Methods

The experimental parameters of the batch test - such as ratio of nanoparticles to soil, ratio of water to soil, and the chemistry of the water - must be optimized such that the observed rate of attachment is neither so fast that it is complete immediately, nor so slow that effectively nothing happens over the period of the test. The optimal experimental variables may vary for each soil type. Mixing speed and conductivity must also be considered as they too influence the rate of attachment. Thus, batch tests have to be repeated adjusting the experimental variables until a robustly measurable extent of attachment is seen (see graph).

The soil and rainwater matrix solution must first be equilibrated by constantly stirring for at least one hour to provide a stable background that can be subtracted from the absorbance of the supernatants at each time point. Following the sampling, the unattached nanoparticle concentrations in the aliquots are immediately measured, using UV-Vis absorbance or single particle ICP-MS, depending on the particles under study.

Used for

LEVEL 5 -**FULL PROTOCOLS** (also feed into OFCD TG & GDs via Malta initiative)





Synthesis






- Zerovalent iron



• Making the hazard tools more realistic, relevant and longer term


PATROLS Vision

of next generation
hazard assessment tools to predict
adverse effects caused by
long-term, low dose ENM exposure
to humans & the
environment, supporting regulatory
risk decision making





Developing advanced hazard testing systems







• Combining different sources of information for risk assessment and decision making



SUN Developed Innovative Tools

Hazard

- In vitro screening tools
- Rapid high-throughput and content tools for predicting long-term environmental consequences and impacts on ecosystem services
- Short-term inhalation and oral studies

Exposure

- A stochastic fate and exposure tool to calculate predicted environmental concentrations (PECs)
- 3-tier qualitative to quantitative inhalation, dermal and dermal-to-oral occupational and consumer exposure assessment tool

Release

- Validated tools to collect manufactured nanomaterials (MN) released from products
- Tools to analyse and characterize the released MN
- Modelling tools to predict the release and transformation of MN over the whole lifecycle

Risk assessment

- A tool for quantitative human health Risk Assessment of MN based on REACH
- A tool for stochastic ecological Risk Assessment based on Species Sensitivity Distributions

Decision support

 A user-friendly, software-based Decision Support System for informing industrial and regulatory decisions about the safe production, handling and disposal of MN

Lifecycle impact

 A comparative LCA model for nanoproducts and MN

Safe product and process design

- Safety by design (S_{by}D) elimination/substitution and waste isolation practices to reduce the release of nanomaterials from
 products/composites/waste or to induce their accelerated alteration/degradation in order to reduce their environmental persistence
 and bioaccumulation
- Tools to analyse the evolution of the product quality parameters, process conditions and interactions, in real-time, to subsequently
 exercise control over them, increasing both product safety and quality





SUN Concept

Bottom-up generation of environmental, health and safety (EHS) data and tools

Top-down design of a Decision Support System for use by industries and regulators







GUIDEnano Tool

Quantitative risk assessment, allowing a justified assessment for each scenario

The tool is not for screening of risks or prioritization, but it supports decisionmaking

It is a complete (hazard & exposure assessment, different exposure routes and scenarios along the life cycle) and flexible Tool (allowing future updates)

The tool matches with existing regulatory accepted risk assessment methods, e.g. REACH, OECD

OVERALL: GUIDEnano enables science—based risk assessment of nanomaterials and nano-enabled products in a more transparent and reproducible way compared to current practice





GUIDE

The Tool Inside

Activities

(Nano)materials

Compartments

Exposure | Hazard Assessment +

Risk Assessment ▼

Report ▼



materials

1

Complete <u>description of</u>

<u>exposure scenarios</u>, including amounts and form of released

Quantification of the Hazard (incorporation of both human and environmental endpoints)
Implementation of the <u>similarity algorithms</u>
for grouping and read-across purposes

Users can <u>define their materials</u> (nanoparticles, nano-enabled products, articles) <u>and their</u> properties along the life cycle

The user can use external tools for human exposure assessment, provide the measured data or use values from <u>GUIDEnano exposure scenario library or release activity</u> card library

Output report for users with details

The user can enter different environmental compartments and different system compartments

<u>Kinetic world fate model</u> has been implemented

Quantitative human and environmental risk assessment with uncertainty factors assigned








• Streamlining physicochemical, exposure, hazard and risk assessment

GRACIOUS FRAMEWORK

Grouping Nanoforms to streamline risk management








GRACIOUS FRAMEWORK

Grouping for regulatory Read-Across








GRACIOUS FRAMEWORK

Grouping for innovation / Safe(r) by Design





https://www.h2020gracious.eu/


























What I have shown you.....



Exposure & Hazard assessment

Contributing projects













CERASAFE SAFE PRODUCTION AND USE OF NANOMATERIALS





































More information can be found at the Cluster NanoSafety Cluster website

https://www.nanosafetycluster.eu/

Exposure & Hazard assessment

NanoSafety Cluster

Progress made 2<u>01</u>4-2017

Release

Westbaring
Washing
Tox Studies

• Environmental fate

- Human Exposure
- Human Hazard
- Ecotoxicology



Exposure & Hazard assessment

Remaining H2020 aims

Match with stakeholder needs

Workshops/webinars with / for industry



• Joint project workshops









NIKC















Open access



Harmonised collection and storage





NOAA in

powder

liauid

solid matrix

ISO standard proactive approach

